



ID	Part Number	Description	Applications
1	QP164550R2	AIR CONDITIONING COMPRESSOR	1640 (Prior to S/N JJC0034705), 1660 (Prior to S/N JJC0038346)
1	QP396829R1	AIR CONDITIONING COMPRESSOR	1640 (S/N JJC0034705 & above), 1660 (S/N JJC0038346 & above)
1	QP1250587C1	AIR CONDITIONING COMPRESSOR	1680
2	QP1970115C1	AUXILIARY PUMP DRIVE	1640 (Prior to S/N JJC0097103), 1660 (Prior to S/N JJC0102897-w/NCE engine)
2	QP191288C2	AUXILIARY PUMP DRIVE	660 (w/Navistar engine), 1680 (Prior to S/N JJC0045689)
2	QP1347387C1	AUXILIARY PUMP DRIVE	1640 (S/N JJC0097103 & above), 1660 (S/N JJC0102897 & above-w/o cross flow cleaning system)
2	QP1541699C1	AUXILIARY PUMP DRIVE	1660 (S/N JJC0103800 & above-w/cross flow cleaning system)
2	QP1970116C1	AUXILIARY PUMP DRIVE	1680 (S/N JJC0045689-JJC0115352)
2	QP1347358C1	AUXILIARY PUMP DRIVE	1680 (S/N JJC0115352 & above)
3	QP195396C2	CLEANING FAN DRIVE	1640, 1660 (w/o extended length cleaning system), 1680

3	QP1541569C1	CLEANING FAN DRIVE	1660 (w/extended length cleaning system)
4	QP181055C1	ELEVATOR DRIVE, W/STRAW CHOPPER	1640, 1660, 1680
4	QP186509C2	ELEVATOR DRIVE, W/DISCHARGE BEATER	1640, 1660, 1680
5	QP537072R92	ENGINE FAN & ALTERNATOR	1640 (Prior to S/N JJC0034705 - use w/Motorola alternator), 1660 (Prior to S/N JJC0038346), 1680 (Prior to S/N JJC0045689 - use w/Bosch alternator)
5	QP1979149C1	ENGINE FAN & ALTERNATOR	1640 (Prior to S/N JJC0034705 - use w/Bosch alternator)
5	QPJ911562	ENGINE FAN & ALTERNATOR	1640 (6TA-590 Engine)
5	QPJ911572	ENGINE FAN & ALTERNATOR	1660 (S/N JJC0038346 & above-w/cross flow cleaning system)
5	QPJ911574	ENGINE FAN & ALTERNATOR	1640 (S/N JJC0034705 & above), 1660 (S/N JJC0038346 & above-w/o cross flow cleaning system), 1680 (S/N JJC0045689 & above)
5	QP131201C92	ENGINE FAN & ALTERNATOR	1680 (Prior to S/N JJC0045689 - use w/Motorola alternator)
6	QP191305C1	FAN JACKSHAFT DRIVE	1640, 1660
6	QP181359C1	FAN JACKSHAFT DRIVE, SLOW SPEED	1640-1660 (67" belt)
6	QP610521R1	FAN JACKSHAFT DRIVE, SLOW SPEED	1640-1660 (74" belt)
6	QP188213C1	FAN JACKSHAFT DRIVE	1680
7	QP192738C1	FEEDER DRIVE, W/O ROCK TRAP	1640, 1660
7	QP1315168C1	FEEDER DRIVE, W/ ROCK TRAP	1640, 1660
7	QP194528C1	FEEDER DRIVE, W/O ROCK TRAP	1680
7	QP1315074C1	FEEDER DRIVE, W/ ROCK TRAP	1680
8	QP1313095C2	FEEDER JACKSHAFT DRIVE, (47" FEEDER)	1640, 1660
8	QP1313097C3	FEEDER JACKSHAFT DRIVE, (54.5" FEEDER)	1640, 1660, 1680
8	QP1308489C2	FEEDER JACKSHAFT DRIVE, (60" FEEDER)	1680
9	QP191290C1	GRAIN TANK UNLOADER DRIVE	1640, 1660 (Prior to S/N JJC0102897)
9	QP1989216C1	GRAIN TANK UNLOADER DRIVE	1660 (S/N JJC0102897 & above)
9	QP191291C1	GRAIN TANK UNLOADER DRIVE	1680 (Prior to S/N JJC0115352)
9	QP1989217C1	GRAIN TANK UNLOADER DRIVE	1680 (S/N JJC0115352 & above)
10	QP1979606C1	REEL PUMP DRIVE, (47" FEEDER)	1640 (S/N JJC0034860-JJC0097170), 1660 (S/N JJC0039130-JJC0103066)
10	QP1330311C1	REEL PUMP DRIVE, (54.5" FEEDER)	1640 (S/N JJC0034860-JJC0097170), 1660 (S/N JJC0039130-JJC0103066), 1680 (S/N JJC0046598-JJC0115000)
10	QP1321564C1	REEL PUMP DRIVE, (47" FEEDER)	1640 (Prior to S/N JJC0034860 & S/N JJC0097171 & above), 1660 (Prior to S/N JJC0039130 & JJC010367 & above)

10	QP1321565C1	REEL PUMP DRIVE, (54.5" FEEDER)	1640 (Prior to S/N JJC0034860 & S/N JJC0097171 & above), 1660 (Prior to S/N JJC0039130), 1680 (Prior to S/N JJC0046598 & JJC0115001 & above)
10	QP1315226C1	REEL PUMP DRIVE, (60" FEEDER)	1680 (Prior to S/N JJC0046598 & JJC0115001 & above)
10	QP1979607C1	REEL PUMP DRIVE, (60" FEEDER)	1680 (S/N JJC0046598-JJC0115000)
11	QP193923C4	ROTOR DRIVE, STD	1640, 1660
11	QP193945C2	ROTOR DRIVE, STD	1680
11	QP244420A1	ROTOR DRIVE, HEAVY DUTY	1640, 1660
11	QP244423A1	ROTOR DRIVE, HEAVY DUTY	1680
12	QP191241C1	SEPARATOR DRIVE	1640, 1660
12	QP191244C1	SEPARATOR DRIVE	1680 (Prior to S/N JJC0045689)
12	QP1330499C1	SEPARATOR DRIVE	1680 (S/N JJC0045689 & above)
13	QP1315265C1	STRAW CHOPPER DRIVE	1640, 1660
13	QP1315266C1	STRAW CHOPPER DRIVE	1680
14	QP196371C1	STRAW SPREADER DRIVE	1640, 1660, 1680
