



Id	Part Number	Description	Applications
1a	QPZ42756	A/C COMPRESSOR	4425, 4435 Hydro
1b	QPZ46759	A/C COMPRESSOR	4435, 4435 Hydro
2	QPAR72036	ALTERNATOR, WATERPUMP	4425, 4435, 4435 Hydro
3	QPZ33790	BEATER	4425, 4435, 4435 Hydro
4	QPZ47912	CLEAN GRAIN ELEVATOR	4435, 4435 Hydro
5	QPZ41178	CLEANING FAN	4425
5	QPZ46365	CLEANING FAN	4435, 4435 Hydro
6	QPZ45482	CONDENSOR FAN	4425, 4435 Hydro
7	QPZ43863	CONDENSER ROTARY BLADE, UPPER & MIDDLE (2)	4425, 4435 Hydro
8	QPZ38704	CONDENSER ROTARY BLADE, LOWER	4425, 4435 Hydro
9	QPZ34786	COUNTERSHAFT TO ROTARY SCREEN	4425, 4435 Hydro
9	QPZ46764	COUNTERSHAFT TO ROTARY SCREEN	4435

10	QPZ32190	CRANKSHAFT TO COUNTERSHAFT	4425, 4435, 4435 Hydro
11	QPZ65924	CYLINDER DRIVE	4425, 4435, 4435 Hydro
12	QPZ38186	FEEDERHOUSE	4425, 4435, 4435 Hydro
13	QPAZ35635	GROUND DRIVE, UPPER	4425
13	QPAZ37807	GROUND DRIVE, UPPER	4435, 4435 Hydro
14	QPZ34099	GROUND DRIVE, LOWER	4425, 4435, 4435 Hydro
15	QPZ53290	HYDROSTATIC DRIVE	4435 Hydro
16	QPZ34828	MAIN HYDRAULIC PUMP	4425, 4435, 4435 Hydro
17	QPZ34405	SEPARATOR	4425
17	QPZ46366	SEPARATOR	4435, 4435 Hydro
18	QPZ44930	STRAW CHOPPER, REAR	4425
18	QPZ47763	STRAW CHOPPER, REAR	4435-4435 Hydro (Prior to S/N 056350)
18	QPZ55645	STRAW CHOPPER, REAR	4435-4435 Hydro (S/N 056350 & above)
19	QPZ44761	STRAW CHOPPER, FRONT	4425, 4435, 4435 Hydro
20	QPZ33774	STRAW SPREADER	4425
20	QPZ32041	STRAW SPREADER	4435, 4435 Hydro
21	QPZ45026	TAILINGS ELEVATOR	4425, 4435, 4435 Hydro
22	QPZ47911	UNLOADING AUGER	4425
22	QPZ51212	UNLOADING AUGER	4435, 4435 Hydro