



ID	Part Number	Description	Applications
1	QP402254R91	ALTERNATOR, FAN, WATER PUMP, V-304 ENG	815
1	QP402253R91	ALTERNATOR, FAN, WATER PUMP, V-345 ENG	815, 915
2	QP574615R1	COMPRESSOR DRIVE, D-407 DIESEL	815, 915
2	QP65337C2	COMPRESSOR DRIVE, D-414 DIESEL	815, 915
3	QP167031C2	COMPRESSOR DRIVE, GAS	815, 915
4	QP174509C1	CYLINDER DRIVE	815, 915
5	QP164006C1	CYLINDER DRIVE, VARIABLE SPEED	815, 915
6	QP167099C1	TACHOMETER SHAFT DRIVE	815, 915
7	QP528419R91	FAN, WATER PUMP, GENERATOR, D-407 ENG	815, 915
7	QP537072R92	FAN, WATER PUMP, GENERATOR, D-414 ENG	815, 915
8	QP176565C1	FEEDER JACKSHAFT DRIVE, SINGLE BELT	815 (S/N 8001 & above), 915 (w/o 23.1-34 or 24.5-32 tires)
8	QP176566C1	FEEDER JACKSHAFT DRIVE, SET OF 2	815 (S/N 8001 & above - use w/23.1 - 34 tires)
8	QP176567C1	FEEDER JACKSHAFT DRIVE, SET OF 3	815 (S/N 8001 & above), 915 (w/o 23.1-34 24.5-32 tires)

<b>8</b>	QP176576C1	FEEDER JACKSHAFT DRIVE, SINGLE BELT	915 (Prior to S/N 19000 - use w/23.1-34, 24.5-32 tires or track)
<b>8</b>	QP176577C1	FEEDER JACKSHAFT DRIVE, SET OF 2	915(S/N 19001 & above - use w/23.1-34, 24.5-32 tires or track)
<b>8</b>	QP176566C1	FEEDER JACKSHAFT DRIVE, SET OF 2	915 (w/o 23.1-34, 24.5-32 tires or track)
<b>9</b>	QP532031R2	GOVERNOR BELT	815-915 (S/N 8001 & above)
<b>10</b>	QP178019C1	KNIFE DRIVE	815-915 (S/N 8001 & above)
<b>11</b>	QP178763C1	REEL PUMP DRIVE, GAS, HYDRO	815-915 (S/N 8001 & above)
<b>11</b>	QP179007C1	REEL PUMP DRIVE, DIESEL, HYDRO	815-915 (S/N 8001 & above)
<b>12</b>	QP168665C2	SEPARATOR DRIVE, DIESEL	815, 915
<b>12</b>	QP166598C2	SEPARATOR DRIVE, GAS	815, 915 (Prior to S/N 19000)
<b>13</b>	QP164999C92	SEPARATOR FAN DRIVE	815, 915
<b>14</b>	QP632702R1	SHAKER SHAFT DRIVE 280 RPM, STD	815, 915
<b>14</b>	QP564494R2	SHAKER SHAFT DRIVE 265 RPM, OPT	815, 915
<b>15</b>	QP160870C1	STRAW CHOPPER DRIVE	815 (Prior to S/N 3784), 915 (Prior to S/N 2350)
<b>15</b>	QP174642C1	STRAW CHOPPER DRIVE	815 (S/N 3784-8001), 915 (S/N 2350-8001)
<b>15</b>	QP177499C1	STRAW CHOPPER DRIVE	815-915 (S/N 8001 & above)
<b>16</b>	QP161820C1	STRAW SPREADER DRIVE	815 (Prior to S/N 3784)
<b>16</b>	QP161821C1	STRAW SPREADER DRIVE	815 (S/N 3784-8001), 915 (Prior to S/N 2350)
<b>16</b>	QP196370C1	STRAW SPREADER DRIVE	815 (S/N 8001 & above)
<b>16</b>	QP196371C1	STRAW SPREADER DRIVE	915 (S/N 2350 & above)
<b>17</b>	QP160173C1	UNLOADER JACKSHAFT DRIVE	815, 915
<b>NI</b>	QP168725C1	ROTARY AIR SCREEN DRIVE, DIESEL	815 (Prior to S/N 3784), 915 (Prior to S/N 2350)
<b>NI</b>	QP172360C1	ROTARY AIR SCREEN DRIVE, DIESEL	815 (S/N 3784 & above), 915 (S/N 2350 & above)
<b>NI</b>	QP38331K	ROTARY AIR SCREEN DRIVE, GAS	815 (Prior to S/N 3784), 915 (Prior to S/N 2350)
<b>NI</b>	QP174967C1	ROTARY AIR SCREEN DRIVE, GAS	815 (S/N 3784 & above), 915 (S/N 2350 & above)
<b>NI</b>	QP160871C1	STRAW CHOPPER JACKSHAFT DRIVE, GAS	815 (Prior to S/N 3784), 915 (Prior to S/N 2350)
<b>NI</b>	QP168678C1	STRAW CHOPPER JACKSHAFT DRIVE, DIESEL	815 (Prior to S/N 3784), 915 (Prior to S/N 2350)